

INSTALLATION

These installation specifications are for all fully adhered installations of Mannington Commercial Nature's Paths luxury vinyl flooring. All recommendations are based on the most recent available information. The information on this sheet provides general guidelines. For complete details consult Mannington's Professional Installation Guide. All instructions and recommendations must be followed for a satisfactory installation.

1. The floor covering, adhesive, and room temperature must be kept at a minimum temperature of 65°F or warmer for at least 48 hours before, during, and 48 hours after installation.
2. Install Nature's Paths only after the jobsite has been cleaned and cleared of other trade apparatus that may damage a finished tile installation.
3. Always check the cartons to assure the pattern number is correct and that the shade and lot numbers are the same on all cartons. To minimize shade variation, mix and install tiles from several different cartons.
4. All subfloor / underlayment patching must be done with a non-shrinking water resistant Portland cement patching compound such as Mannington MVP-2023.
5. Never install Mannington Commercial Nature's Paths over residual asphalt-type (cut back) adhesive. It can bleed through the new floor covering. Residual asphalt type adhesive must be covered with underlayment plywood or Mannington MVP 2023 cement patching compound mixed with latex additive.
6. Nature's Paths are to be adhered with Mannington Commercial V-82 adhesive or Mannington Commercial V-85 Adhesive.